Model RGLB-00

Installation Instructions

Ranger LockGuard™

LOCK BOX

Installation Instructions

1. Place lock box on right door; back slot extending left of the seal. Weld or bolt on.
2. Place retainer on left door with small holes against door. Part fits in the middle of the slot in the box. Weld or bolt on. Install lock.

Instructivo de instalación

1. Coloque caja de cerradura en la puerta correcta; atrás extender de ranura dejó del sello. La soldadura o cierra en.
2. Coloque iguala en la puerta izquierda con pequeños hoyos contra puerta. La parte queda en medio de la ranura en la caja. La soldadura o cierra en. Instale cerradura.

SGM Enterprises, LLC • Greenville, SC • 866-988-LOCK • www.rangerlock.com

Patented, manufactured to exclusive Ranger Lock specifications in China for SGM Enterprises, LLC.

Ranger Lock